

INSTALLATION AND ASSEMBLY INSTRUCTIONS



STRAUBELSTONE STEELMAN & EXECUTIVE GAS BARBECUE CART UNDER SHELF

This StraubelStone Steelman Gas Barbecue Cart Under Shelf has been designed as a retro-fit accessory, for the StraubelStone Steelman Gas Barbecue Cart. Other accessory items are available from your retailer, or may be purchased by contacting the StraubelStone Customer Service Center.

GENERAL INFORMATION

These instructions are intended as a general guide and do not supersede national or local codes in any way. Authorities having jurisdiction should be consulted before installation.

!!! IMPORTANT !!!

Read these instructions carefully before installation. These instructions should be left with the homeowner for future reference.



GAS-FIRED OUTDOOR COOKING APPLIANCE IN ACCORDANCE WITH THE AMERICAN NATIONAL STANDARDS INSTITUTE (ANSI) STANDARD FOR OUTDOOR COOKING GAS APPLIANCES Z21.58-1995 83EK

SHIPPING AND PACKING LIST

SHIPPING CARTON CONTAINS:

- 1- StraubelStone Steelman Gas Barbecue Cart Under Shelf
- 1- Front Shelf Leg
- 1- Rear Shelf Leg
- 8- 1/4 - 20 x 1/2" Stainless Steel Button Head Screws
- 8- 1/4" Stainless Steel Washers

SET UP AND ASSEMBLY

- 1- **TURN OFF THE GAS SUPPLY!** NEVER attempt any assembly operation while the appliance is in operation or is HOT.
- 2- Open the shipping container.
- 3- Remove all contents from the shipping container.
- 4- Check the contents of the shipping container against the shipping and packing list. Report any missing or damaged parts to your retailer.
- 5- Locate the Front Shelf Leg (Front Shelf Leg has a notched out corner at the top), two (2) Button Head Screws, and two (2) washers.
- 6- Align the top of the Front Shelf Leg (notched out section) with the front left corner of the under shelf. (SEE FIGURE 1)
- 7- Using a 5/32" male hex driver, attach the leg to the Under Shelf, using two (2) Button Head Screws and two (2) washers, but do not tighten.
- 8- Attach the remaining Rear Shelf Leg in the same manner. Again, do not tighten.
- 9- Locate and remove, two (2) factory installed Button Head Screws, on the right hand side cart legs, at about the midpoint of the leg, on the interior side of the leg.
- 10- Align the right hand side mounting holes of the Under Shelf, with the two (2) mounting holes on the interior side of the right hand cart legs. (SEE FIGURE 2)
- 11- Using a 5/32" male hex driver, attach the shelf to the interior side of the legs, with two (2) Button Head Screws and two (2) washers, but do not tighten.
- 12- Align the front and rear leg, lower mounting holes, at the bottom of each leg, UNDER the mounting holes in the front and rear lower struts of the barbecue cart.

SET UP AND ASSEMBLY continued

- 13- Using a 5/32" male hex driver, attach the Under Shelf legs to the cart struts, using two (2) Button Head Screws and two (2) washers, but do not tighten.
- 14- Check the assembly for a flush and level fit, and then tighten all screws evenly. Do not over tighten.



FIGURE 1



FIGURE 2

STRAUBELSTONE™

16781 Noyes Ave.
Irvine, CA 92606

(800) 640-7687
(949) 296-0121
(949) 296-0127 fax

e-mail – support@straubelstone.com